



Divator Pro for cylinder pack


2024 December

READ BEFORE USE

1. Only holders of a valid Interspiro Service Certificate may carry out service and repairs on Interspiro breathing equipment. Unauthorized service may result in malfunction and users relying thereon could sustain severe respiratory injury or death.
2. When using the spare part list always refer to the equipment's Service manual in regard to procedures and handling of the spare parts assembly and function.
3. Changes to this document – necessitated by typographical errors, inaccuracies of current information or improvements and changes of equipment – may be done at any time and without prior notice. Always refer to the Interspiro webpage for the latest version.
4. The description defines if the spare part is a multi-pack, e. g. "10 x 336100437" indicates that this is a multi-pack that consists of 10 pieces of the single component 336100437. The single component part number 336100437 can not be ordered, it is only used to label parts included in service kits.
5. The service kits contain replacement items used for preventive maintenance.
6. Always refer to the Interspiro webpage for product and document updates and important notices.

Spare Parts Divator Pro Regulator

2023-12-18



Spare Parts Divator Pro Regulator

Position	Item number	Description
1	460190711	Service kit cylinder connection
2	57645-51	Service Kit Divator Pro regulator unit
3	57645-52	Service Kit Divator Pro pressure regulator
4	57561-51	Service Kit Divator Pro warning unit
5	88299-51	Blank plug
6	57543-51	O-ring, 1 x 336900390
7	89129-51	Screw
8	87524-51	Cover
9	336190229	O-ring, 10 x 336900041
10	346190022	O-ring, 10 x 346900002
11	460190386	Piston
12	346190026	Spring, 5 x 346100005
13	97192-51	Plug 7/16-20 EN250
14	336190381	O-ring, 10 x 336900106
15	87463-51	Hand wheel
16	336190232	O-ring, 10 x 336900044
17	88804-52	Connection nipple, short
18	346190643	Inlet filter, 10-pack (10 x 212100014)
19	460190382	Sealing nipple
20	336190272	O-ring, 10 x 331100767
21	460190557	Protection cap, hand wheel, 10 x 336900327
22	97698-52	Supporting washers & O-ring
23	346190028	Spring, 5 x 336100280
24	97698-51	Valve seat assembly
25	460190269	O-ring, 2.6 x 1.3, 10 x 346900015


Spare Parts Divator Pro Regulator

Position	Item number	Description
26	99732-54	Stop screw
27	336190790	O-ring, 10 x 336900268
28	88288-51	Spring housing
29	88180-01	Safety pressure unit
30	88286-01	Diaphragm nut
31	460190421	Cap, 10 pack (10 x 336100604)
32	336190380	Split pin, 10-pack (10 x 336900104)
33	460190441	Nut, 5 pack (5 x 336100606)
34	87439-51	Handle, Divator Pro
35	460190430	Torsion spring, 5 pack (5 x 336100605)
36	460190428	Nipple, 5 pack (5 x 336100407)
37	336190382	O-ring, 10 x 336900103
38	336190404	Valve stem assy MKII
39	336190595	O-ring, 10 x 336900165
40	336190383	Valve disc, 5-pack (5 x 336100412)
41	31776-51	Underwater quick connector, female
42	99265-51	Pressure gauge, diving, bar
43	336190159	Gasket set, 1 x 335100368 & 1 x 335100369
44	87440-51	Cover
45	89134-51	Gasket
46	89141-51	Washer
47	89142-51	Spring
48	89132-54	Piston
49	336190311	O-ring, 10 x 944610206
50	87438-51	Blank plug

Spare Parts Divator Pro Regulator

Position	Item number	Description
51	87450-51	Cover holder
52	57562-51	Screw
53	57575-105	Breathing hose, 1.05 M
54	57578-110	Medium pressure hose, 1.1 M
55	57577-110	High pressure hose
56	57576-100	Dry suit inflation hose 1 M
57	336190237	O-ring, 10 x 3369000099
58	57672-52	O-ring, 10 x OR4,1X1,6-E70

Spare Parts Divator Pro harness & BC



Spare Parts Divator Pro harness & BC

Position	Item number	Description
1	57678-52	Service kit, Divator Pro BC, routine maintenance
2	57678-55	Service kit, Divator Pro BC, full service
3	57680-51	Non return valve
4	57681-51	O-Ring, 15x4
5	57696-51	O-ring
6	57682-51	O-Ring 9,12x3,53
7	57683-51	Relief valve sealing
8	57684-51	Protective rubber
9	57654-52	Zip tie
10	57696-52	O-ring
11	57646-51	Screw, RTS ST2,9
12	57647-51	Button
13	57648-51	Compression spring
14	57649-51	Kit for komplette MP valve
15	88336-51	Quick connector Male
16	57644-51	Dump valve insert
17	57711-51	Plug with o ring
18	57712-51	BC emergency inflation assembly
19	57715-51	Dump valve axis with string
20	88263-54	Pin
21	57716-51	Hose clip with elastic string.
22	57679-52	Inflator unit Pro incl. Connection
23	87397-52	Pro Dump valve upper, complete set
24	87398-52	Pro Dump valve lower, complete set
25	57669-52	Pro Plug assembly

Spare Parts Divator Pro harness & BC

Position	Item number	Description
26	57548-52	Inflator cylinder connection Divator Pro
27	57713-51	BC connector
28	57609-51	BC connector lid
29	57709-51	O-ring 7,65x1,78
30	30146-01	Inflator cylinder, 0.35 L - in-line cylinder valve
31	57549-51	Holder for inflation cylinder
32	87515-51	Weight bracket
33	57665-51	Weight release kit
34	87096-51	Weight holder kit
35	99431-51	Elastic cord loop with knob, 5-pack
36	57664-51	Relief loop
37	99711-852	Screw, 10 x 99711-802
38	57663-51	Buckle holder kit
39	57662-51	Hose holder kit
40	57661-51	D-ring kit
41	88265-51	O-ring
42	87073-51	Waist buckle
43	87525-52	Waist belt, right
44	87525-51	Waist belt, left
45	57660-51	Waist belt holder plate
46	57666-51	Tri-glide D-ring
47	57659-51	Adjusting strap, shoulder
48	87308-55	Buckle, male, 2-pack
49	87308-53	Buckle, female, 2-pack
50	57656-51	Shoulder strap unit

Spare Parts Divator Pro harness & BC

Position	Item number	Description
51	57658-51	Rotary handle
52	57657-51	Backplate Divator Pro
53	33466-51	Backplate clip, 2 x 33466-01
54	57655-51	Handle
55	57718-51	Pro bladder, without valve/connectors