

Blade Nozzles

QUICK START GUIDE

1 Orienting the blade to the shutoff

Rotate the nozzle until the blade pattern insert (blue triangle) is aligned with the shutoff handle as shown. When the raised fin is in line with the blade pattern insert the nozzle is in wide blade mode.



2 Switching between solid blade and solid tight stream

For a solid tight stream turn the outer collar a quarter turn to the right. To return to the wide Blade or a stream width in-between, rotate the outer collar back to center line. For most applications we recommend the blade pattern.



3 Locking swivel rotation (if equipped)

Rotate the knob to UNLOCK to adjust, then orient the nozzle to the position you desire. Rotate back to LOCK and turn the nozzle slightly to engage.



For any questions about your new HEN nozzle, please contact:

Eric Guida • Director, Sales
(530) 574-0634 • eric.guida@hennozzles.com