

- In addition to routine checks for each use, PPE should regularly undergo a detailed inspection by a competent person. Petzl recommends an inspection every 12 months and after any exceptional event in the life of the product.
 - PPE inspection should be conducted with the manufacturer's Instructions for Use.
- Download the instructions at [PETZL.COM](https://www.petzl.com).



ASAP

User information

Surname

Address

Identifier

PPE information

Model

Serial number

Year of manufacture

Date of purchase

Date of first use

Manufacturer: Petzl, ZI Cidex 105A - 38920 Crolles - France

☒ Good condition (G)	☐ To monitor (TM)	☐ To repair (TR)	☐ Do not use, retire (R)	☐ N/A Not applicable
---	---------------------------------------	--------------------------------------	--	--

1. Known product history

Usage conditions or exceptional event during use (examples: fall or fall arrest, use or storage at extreme temperatures, modification outside manufacturer's facilities...):

☒	☐	☐	☐	☐	N/A
----------------------------------	-----------------------	-----------------------	-----------------------	-----------------------	-----

2. Preliminary observations

Verify the presence and legibility of the serial number and the CE mark.
Verify that the product lifetime has not been exceeded.
Compare with a new device to verify there are no modifications or missing elements.

☐	☐	☐	☐	☐
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

3. Inspecting the frame

- Check the condition of the frame (marks, deformation, cracks, corrosion...).
- Check the condition of the edges of the attachment hole (marks, deformation, cracks are a sign of fall arrest).
- ASAP B71 only:
Check the condition of the wheel stop (marks, deformation, cracks are a sign of fall arrest).
Check the condition of the protective cover.

☐	☐	☐	☐	☐
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

4. Inspecting the wheel

- Check the condition of the wheel (marks, deformation, cracks, corrosion...).
- Verify that all teeth are present and check their state of wear.
The wheel must not be fouled. If necessary, clean it with a brush, possibly by applying solvent with a fine brush. Avoid getting any liquid inside the mechanism.
- Check the rotation of the wheel.
Turn the wheel one complete revolution in both directions, making sure it rotates smoothly, without catching.

☐	☐	☐	☐	☐
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

5. Checking the arm and the safety catch

- Check the condition of the arm (marks, deformation, cracks, corrosion...).
- Check the condition of the safety catch (marks, deformation, cracks are a sign of fall arrest).
- Check the effectiveness of the arm's return spring.

☐	☐	☐	☐	☐
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

6. Function test: sliding on the rope

- Install the ASAP on a compatible rope, check that it slides properly on the rope in both directions.

☐	☐	☐	☐	☐
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

7. Function test: grabbing and releasing the rope

- Install the ASAP on a compatible rope; test for correct locking by pulling downward (direction of a fall).
- After locking, verify that releasing is normally carried out.

☐	☐	☐	☐	☐
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

8. Checking the condition of the OK TL connector

- For connector inspection, see the inspection form for your connector model at petzl.com.

☐	☐	☐	☐	☐
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

Comments (detail here any defects found on the product and accomplished tasks)

VERDICT

- ☐ Product **fit** to remain in service
- ☐ Product **unfit** to remain in service

Inspected by

Company

Date Next inspection date