



Product Specifications

Model: 1690D Portable Heater

Description:

Designed to be paired with the Pelsue 1325D series axial blower and any liquid propane fuel source. The heater and blower combination will provide a completely portable source of heated fresh air. Intended to be used in the temporary heating of manholes, vaults and buildings under construction, alteration or repair.

General Specifications:

Voltage: 120V AC, 50/60 HZ

Amperage: 1 amp

Heat Output: 70,000 BTU (73,850 Kj)

Heat Rise: 100° F (37.8° C) at outlet of heater

Width: 13.5" (34.9 cm)

Length: 18.50" (46.9 cm)

Height: 15.25" (38.74 cm)

Weight: 30 lbs (13.6 Kg)

Materials & Construction:

Aluminum housing

Stainless steel heat exchanger

Rubber handle

Brass fittings



Other Features:

CSA certified in Canada and the United States.

The heater can be connected to any liquid propane (vapor) cylinder meeting ANSI/NFPA 58-1986 and CAN/CGA-B149.2 current edition, 20 lb to 100 lb cylinders being the most widely used.

T.A. Pelsue Company

2500 S. Tejon St.

Englewood, CO 80110

Ph: 800-525-8460, (303) 936-7432

Fax: (303) 934-5581

Web: www.pelsue.com

E-mail: sales@pelsue.com