

CMC PROSWIVEL™ PULLEYS



CLASSIFIED TO NFPA 2500
GENERAL AND TECHNICAL USE

SCAN FOR
MORE DETAILS



The CMC ProSwivel Pulleys combine a swivel and pulley into one tool with a unique sideplate that opens while the pulley is still attached to the anchor. Teaming up with Rock Exotica, CMC now offers more swivel pulleys certified to NFPA standards. Our renamed and expanded ProSwivel™ line includes eight pulleys to choose from so you can pick the best CMC ProSwivel Pulley for the job.

CMC also offers two SwivaBiners that combine a swivel, pulley, and carabiner into a single compact device with a double-detent sideplate that opens while the pulley is still attached to the anchor. They are an excellent option for mechanical advantage systems for hauling and ascending, and they work well in combination with high anchors, tripods, and redirects.

FEATURES & BENEFITS

- New models available including efficient 2" pulleys and lightweight 1.1" double pulleys.
- Patented, USA Made, time-tested, and proven as the original swivel pulleys
- Combined swivel & pulley reduces system length, allowing more travel
- Pivoting sideplate allows rope loading without disconnecting from anchor
- Double-action detent button prevents accidental opening of the sideplate
- Sheave is mounted on sealed ball bearings for maximum efficiency
- Rotating swivel aligns rope with the direction of pull
- Swivel can be secured using rope, web, or carabiners
- Ergonomic design for anchoring and loading with one hand
- CNC machined for optimal strength & weight
- Prusik minding options facilitate progress capture
- Compatible with rope up to 13 mm (1/2 in)
- 1.5" PMP SS Pulley is compatible with rope or wire cable
- Ideal for rescue, work at height, and tree care













CMC PROSWIVEL™ PULLEYS



CLASSIFIED TO NFPA 2500
GENERAL AND TECHNICAL USE

SCAN FOR
MORE DETAILS



Photo	Item #	Model	Weight	Pulley Type	Sheave Material	Height X Width	Color	NFPA Rating	3 Sigma MBS
	300435	1.1" PMP SwivaBiner Pulley	200 g (7.0 oz)	Single Sheave	Aluminum	112 x 51 mm (4.4 x 2 in)	Black	T-rated	22 kN (4,946 lbf)
	300439	1.1" PMP SwivaBiner Double Pulley	298 g (11 oz)	Double Sheave	Aluminum	112 x 51 mm (4.4 x 2 in)	Black	T-rated	22 kN (4,946 lbf)
	300434	1.1" PMP Single Swivel Pulley	147 g (5.2 oz)	Single Sheave	Aluminum	112 x 51 mm (4.4 x 2 in)	Bronze/ Slate	T-rated	22 KN (4,946 lbf)
	300433	1.1" PMP Double Swivel Pulley	245 g (7 oz)	Double Sheave	Aluminum	112 X 51 mm (4.4 X 2.0 in)	Bronze/ Slate	T-rated	22 KN (4,946 lbf)
	300430	1.5" PMP SS Single Swivel Pulley	331 g (11.7 oz)	Single Sheave	Stainless	148 x 76 mm (5.8 x 3 in)	Bronze/ Slate	G-rated	36 kN (8,093 lbf)
	300431	1.5" Single Swivel Pulley	261 g (9.2 oz)	Single Sheave	Aluminum	135 X 63 mm (5.3 X 2.5 in)	Bronze/ Slate	G-rated	36 kN (8,093 lbf)
	300432	1.5" Double Swivel Pulley	415 g (14.6 oz)	Double Sheave	Aluminum	160 X 63 mm (6.3 X 2.5 in)	Bronze/ Slate	G-rated	36 kN (8,093 lbf)
	300437	2.0" PMP Single Swivel Pulley	349 g (12.3 oz)	Single Sheave	Aluminum	148 X 76 mm (5.8 x 3 in)	Bronze/ Slate	G-rated	36 kN (8,093 lbf)
	300438	2.0" PMP Double Swivel Pulley	585 g (20.6 oz)	Double Sheave	Aluminum	180 X 76 mm (7.0 X 3 in)	Bronze/ Slate	G-rated	36 kN (8,093 lbf)
	300436	2.0" PMP DOUBLE SWIVEL PULLEY	841 g (29.7 oz)	Single Sheave	Aluminum	191.3 X 92.5 mm (7.53 X 3.62 in)	Bronze/ Slate	G-rated	70 KN (15,737 lbf)