



CLASSIFIED TO NFPA 2500
GENERAL USE



SCAN FOR
MORE DETAILS



The CMC Triskelion is a fully featured industrial rescue tripod that sets a new benchmark for rapid deployment, ease of use, and versatility. With its 5.5 – 10 ft working height, certification to NFPA and EN standards, and multiple rigging options, the Triskelion delivers greater safety and efficiency for confined space and industrial rescues.



10 ft Max Height



Rapid Deployment



NFPA G-rated

FEATURES

- Third-party certification to NFPA General Use, EN 795, and CEN/TS 16415 assures the Triskelion meets the minimum breaking strength of each standard.
- 10 ft max working height allows rescuers to haul patients from a confined space using a harness or litter and 5.5 ft min working height facilitates access in low-clearance areas. 4 in leg increments help fine tune tripod height.
- Rectangular legs with built-in stoppers, tethered push pins, and high contrast graphics allow teams to quickly and easily align adjustment holes and set the desired height.
- Includes leg packing strap and reinforced carry bag with diagram for proper packing, easily carried by two people using end handles or a single person using the padded center shoulder strap.
- Supported by custom accessories that enhance its capabilities and make it even easier to use including Triskelion Winch Adapters, Foot Steps, and Ground Stakes.
- A single red webbing hobble strap secures all three legs at the base with a quick-connect Cobra Buckle, creating a system that is easier to see and lighter weight than chain, and faster than using multiple lengths of material.



760001

SPECIFICATIONS

- Footprint inside Ø of feet 1580 - 2820 mm (62.2 - 111 in)
- Footprint outside Ø of feet 1930 - 3170 mm (76 - 125 in)
- MBS attached direct to head 36 kN (8,093 lbf)
- MBS attached to leg over pulley 22 kN (4946 lbf)

Item #	Option	Weight	Dimensions (mm)
760001	CMC Triskelion Tripod	32 kg (70 lb)	1700 x 310 x 310
760015	Triskelion Foot Step Kit (2)	1.3 KG (2.8 lb)	224 X 286 X 360
760016	Triskelion Ground Stake Kit (3)	3.1 KG (6.8 lb)	312 X 321 X 321
760017	Triskelion Equipment Bracket	1.0 KG (2.2 lb)	146 X 127 X 146
760012	Triskelion LokHead Winch Adapter	2.8 KG (6.2 lb)	240 X 170 X 132
760014	Triskelion Salalift II Winch Adapter	1.6 KG (3.5 lb)	140 X 101 X 110

ACCESSORIES



760015



760016



760017



760012



760014