

Divator Pro for cylinder pack



Technical specification

- ✓ Approval : 2014/68EU (PED)
- ✓ Standard : EN250 (incl. cold water & buddy breathing)
- ✓ Standard (2) : EN1809
- ✓ Material : BC - Trilaminated Polyurethan
- ✓ Lift capacity : 19 kg
- ✓ Warning level : 55 bar

Product description

The unique Divator Pro system is designed to meet specific requirements from the military, rescue services and other professional divers. Simplicity for the user, durability and safety characterize the system. The system can be configured in a number of different variants within its CE approval. This increases the security of the diving organization, which can then have a single supplier with system responsibility.

Divator Pro can, for example, be configured for fast life-saving operations as well as for longer work at greater depths. The simple handling and durability also make Divator Pro suitable for training of divers, something that normally causes a lot of wear and tear on the equipment.

- Delivered as a completely tested and approved EN250 system
- Can be varied in a number of configurations within the current approval
- The hose routing is adapted to minimize the risk of getting stuck
- Easy operation facilitates rapid deployments
- The soft parts are mainly made of plastic and rubber to give short drying time and easy cleaning

The regulator has an anti-freezing protection with safety pressure, which prevents water from entering and eliminates the risk of freezing. At low cylinder pressures, a reserve air warning is activated so that no diver can miss to interrupt the dive in time.

The harness can be equipped with an integrated BC bladder that can be mounted / disassembled by hand before diving. The unique waist belt and buckle facilitate donning, reduce the risk of hanging straps getting stuck and are adjustable in several sizes.

Together with the size adjustment of the height of the harness, a single variant can cover all body sizes. Therefore there is no longer any need to purchase and manage BCs with different sizes within the organization.

The apparatus uses the legendary Divator full face mask and cylinder pack with full composite cylinders or steel cylinders with a newly developed attachment system to the harness/BC.