

THE COLOUR RANGE is intended as a guide only. Please contact a Pacific Helmets representative or distributor for a true colour swatch.
Custom colours available by request, minimum order quantity may apply.



PACIFIC HELMETS (NZ) LTD
SAFETY WITHOUT COMPROMISE

315 Heads Road / PO Box 866
Wanganui 4501
New Zealand

Phone: + 64 6 344 5019
Fax: + 64 6 344 5376

sales@pacifichelmets.com
www.pacifichelmets.com



R6L PATROLLER

WILDLAND FIREFIGHTING / TECHNICAL RESCUE
INDUSTRIAL SAFETY

CERTIFICATION
ANSI Z89.1:2014, AS/NZS1801:1997 T1/2/3,
EN16471:2014, EN16473:2014,
EN12492:2012, EN397:2012, NFPA1851:2020





R6L PATROLLER

WILDLAND FIREFIGHTING / TECHNICAL RESCUE
INDUSTRIAL SAFETY

CERTIFICATION
ANSI Z89.1:2014, AS/NZS1801:1997 T1/2/3,
EN16471:2014, EN16473:2014,
EN12482:2012, EN397:2012, NFPA1851:2020

DuPont™ Kevlar® and Fibreglass Reinforced Composite Shell provides integral strength and excellent penetration protection. This lightweight shell is chemical and UV resistant with inherent heat and flame resistance. Expected service life of 15+ years with proper care and maintenance.

Rails (optional) for attaching multiple accessories. Earmuff Brackets also available. Note: rails and earmuff brackets not compatible.

Pacific edge beading provides extra shell durability.

Pacific ratchet adjustable headband, sizing range from 52–65cm (downsizing adjustment kits and XL sizes available). Simple operation with a single gloved hand. Comes with comfortable front and rear sweat padding in your choice of leather, merino, or vinyl and is easily removable and replaceable for decontamination.

4-point chin strap. Single handed adjustment at multiple locations for maximum comfort and stability. Chin cup or chin loop optional.

Pacific low profile buckle can be easily secured, released, and adjusted with a gloved hand.



Unique PU cap provides excellent shock impact absorption and a thermal barrier.

VAS Shroud for attaching accessories (optional).

6-point clip in ribbon cradle harness, fully modular for easy decontamination and replacement without special tools.

Other Optional accessories available:

- **Premium reflective trim** with high retro-reflectivity for increased visibility
- **Customised Decals** (badges, wording, and rank markings)
- **Lamp attachments:** 4pt Front Bungy or Front Rubber Straps. *Note: incompatible with VAS shroud.*
- **Goggle Straps or Goggle Posts**
- **Easi-On-Off (EOB) torch base.** Easi Glide Torch Holder and torch sold separately
- **Water Release Holes**
- **Flame Resistant Neck Protector**
- **Clear polycarbonate face shield or eye protector** to provide high speed particle impact protection. *Note: incompatible with Rails.*
- **Earmuff Brackets** for 25mm or 30mm earmuff fittings. *Note: incompatible with Rails.*