



EW22G SOFT-MOUNT EXTRACTOR

NFPA 1851 COMPLIANT

Commercial Extractor tumbles PPE gear with a front load design and soft-mount installation.



STANDARD FEATURES

- Can wash 4 pieces of turnout gear per load
- Stainless steel inner tub (capacity: 3.7 cu ft)
- Easy soft-mount installation
- With fewer overall moving parts; Promotes longer life expectancy
- Meets NFPA 1851:2020 Requirements
- Complete with manual/manufacture's warranty
- Hot and Cold hoses come with unit
- PPE Washing Programs: Spin Cycle G-Force Under 100 G's
- Towels Washing Program: Spin Cycle G-Force 451 G's
- A backflow preventer is built into the supply dispenser

ELECTRICAL

- Runs on 120 volts (watts per load: 110-160 watt hours)
- Fuse: 250V, 12 A (Time Delay)
- 6' electrical cord with plug comes off the back of the extractor.

PLUMBING

- There is a 6' flexible drain hose that comes off the back of the extractor. The drain hose should be inserted into a 2" standing drain pipe or attached to a nearby slop sink or laundry tub.

WASH CYCLES (All Times are Approximate)

Blood Bourne	Hot wash cycle to be used with PPE gear disinfectant laundry solution Cycle: Total time - 30 minutes
Outer Shells / Liners	NFPA 1851 warm wash cycle for PPE outer shells & liners Cycle: Total time - 57 minutes
Cold	PPE cold wash cycle. Cycle: Total time - 52 minutes
Towels	Warm wash cycle for station towels & rags *Do not wash personal or shower/bath towels in extractor *Do not wash PPE gear on Towels program Cycle: Total time - 47 minutes
Super Wash	Extended warm wash cycle for heavy soiled PPE gear Cycle: Total time - 63 minutes

Water usage on average will be about 13-14 gallons per cycle. This will vary depending on water absorption of the fabric.

Fill time and drainage time is 4-5 gal/min

TECHNICAL SPECIFICATIONS

EW22G SOFT-MOUNT EXTRACTOR

Machine Type		Extractor
Product Name		Extractor 220
Product No.		EW22G
Color		Gray
Main Data		
Type		Soft-Mount
Capacity, pieces turnout gear		4
Capacity (dry weight)	lbs / kg	22 / 10
Interior capacity	cu ft / L	3.7 / 104.8
Electrical Installation		
Electrical connection	v / Hz / Ph	120 / 60 / 1
Fuse		250v, 12 A (Time Delay)
Dimensions		
Outer: width x depth x height	in / mm	27.0 x 30.2 x 38.7 / 686 x 767 x 983
Depth with door fully open	in / mm	52.6 / 1336
Shipping dimensions	in / mm	36 x 36 x 58 / 914 x 914 x 1473
Weight		
Weight	lbs / kg	196 / 88.9
Shipping weight	lbs / kg	250 / 113.4

SHIPS FROM:

Groves Incorporated
818 Trakk Ln
Woodstock, IL 60098

