



HIGH-CUT



MID-CUT



FULL-CUT



EPIC™ SPECIALIST

The EPIC™ Specialist Ballistic helmet features exceptional performance and is substantially lighter than the ACH. It offers premium comfort and comes configured with the Team Wendy CAM-FIT™ Dial Retention, EPIC Air® Fit liner system, side accessory rails, Velcro®, shock cords and NVG shroud.

PERFORMANCE STANDARDS

- > NIJ IIIA (according to NIJ STD 0106.01/0108.01)
- > 9mm BFD < 25.4 mm
- > 17gr $V_{50} \geq 2560$ f/s (780 m/s)
- > Meets ACH Gen II Blunt Impact (AR/PD 1401) and AEP 2902 clause 4.1.1.1 Method H

WEIGHT

Complete system weight includes helmet shell, CAM-FIT™ retention, EPIC Air® Fit liner, side accessory rails, Velcro®, shock cords and NVG Shroud.

	SHELL:	Complete System:
> Small	2.11 lbs (0.96 kg)	2.91 lbs (1.32 kg)
> Medium	2.17 lbs (0.98 kg)	2.97 lbs (1.35 kg)
> Large	2.42 lbs (1.10 kg)	3.23 lbs (1.47 kg)
> XL	2.62 (1.19 kg)	3.44 lbs (1.56 kg)

	SHELL:	Complete System:
> Small	1.84 lbs (0.84 kg)	2.64 lbs (1.20 kg)
> Medium	1.9 lbs (0.86 kg)	2.7 lbs (1.22 kg)
> Large	2.01 lbs (0.91 kg)	2.82 lbs (1.28 kg)
> XL	2.26 lbs (1.02 kg)	3.08 (1.40 kg)

* Mid-Cut available as special request

SIZING

	(S)	(M)	(L)	(XL)
Head Circumference (cm)	52-54	54-57	57-60	60-64
Head Circumference (in)	20.5-21.25	21.26-22.4	22.5-23.5	23.6-25.2



SHELL ASSEMBLY

- > Ceradyne Seamless Shell Technology
- > External Velcro® Panels: Military grade loop 1100
- > Innovative No Thru-Hole construction for retention system, rails & NVG shroud attachment
- > Durable polycarbonate edge trim design

TEAM WENDY EPIC AIR® FIT LINER SYSTEM

- > 3 EPIC AIR® Fit Impact Liner Pads (rear, crown, front)
- > 5 Thin Comfort Pads with antimicrobial wicking fabric
- > Proprietary Zorbium® foam technology
- > Proprietary water-resistant film and loop fabric covering

TEAM WENDY CAM FIT™ RETENTION SYSTEM

- > No Thru-Hole Attachment (No drilled holes through the ballistic shell for attachment)
- > Connects to helmet edge trim via custom clip system
- > BOA® fit system with micro-adjustable dial, coated stainless steel cable and low friction guides
- > MIL-DTL-32067 leather chin cup
- > 5/8" nylon webbing
- > Acetal buckles and cams
- > 500 D Cordura nape pad with Zorbium® foam
- > Antimicrobial wicking headband sleeves

ACCESSORY RAIL

- > No Thru-Hole Attachment (No drilled holes through the ballistic shell for attachment)
- > Integrated low profile reverse dove-tail mounting system
- > Accommodates common helmet accessories
- > Accepts optional removable picatinny adapter
- > Counterweight attachment provisions
- > Accommodates shock cord system to increase stability for the Night Vision Device

ACCESSORY NVG SHROUD

- > No Thru-Hole Attachment (No drilled holes through the ballistic shell for attachment)
- > Accepts all common industry night vision goggle (NVG) adapters

COLORS



Black (FED-STD-595C #37031)



Coyote Brown (FED-STD-595C #20150)



Ranger Green (Pantone 7770c)

AVAILABLE ACCESSORIES

DK7-H PAULSON RAIL MOUNTED RIOT FACE SHIELDS

Available with and without liquid seal

PICATINNY RAIL ADAPTER

Utilized to attach lights and other accessories to rails

COUNTERWEIGHT KIT

Offers increased stability while utilizing NVG shroud

CHINSTRAP EXTENDER (4")

Utilized to extend helmet retention to utilize with Avon Protection respirator

Full list of compatible accessories available on [TeamWendy.com](https://www.teamwendy.com)

GR05862-01 Copyright © 2023 Team Wendy. All rights reserved.