



PORTABLE SCENE LIGHT II

RECHARGEABLE HIGH LUMEN SCENE LIGHT



Stackable for "light tower" capability



Hooked feet to hang over doors, guide rails, fences, etc.



Digital display shows intensity level and run time

Toggle switch - choose from 5 intensity levels

Material/Lens High-impact thermoplastic sealed rotating housing mounted in a rugged alloy steel frame. Frames nest for stacking. Unbreakable polycarbonate with scratch-resistant coating. O-ring sealed.

Dims/Weight Length: 16 in. (40.6 cm) Body Width: 11 in. (27.9 cm) Overall Height: 12 in. (30.5 cm)
15.56 lbs (7.06 kg) with batteries (included in purchase)

Light Source 18 LEDs within wide pattern parabolic reflectors produce a smooth, high lumen flood pattern

Output/ Runtime 18 wide pattern parabolic reflectors produce 10,000 lumens in a smooth pattern. Optimized electronics provide fully regulated intensity; Indefinite run time with AC/DC power cord.

	100%	80%	60%	40%	20%
LUMENS	10,000	8,300	6,300	4,500	2,300
RUN TIME	2 hours	2.75 hours	3.75 hours	5.75 hours	11 hours

Switch Toggle switch operation features five intensity adjustments that reveals corresponding runtime adjustment on the LED Display.

Battery Lithium Ion battery with on-board safety control circuit, rechargeable up to 800 times. Lithium ion batteries charge in 6 hours. PSL II battery will continue to charge while operating directly from an external power source when using the 12VDC cord or AC charger.

Features

- Regulated light output throughout battery life.
- IPX7 rated; waterproof to 1 meter for 30 minutes.
- Serialized for positive identification.
- Head rotates 360°

Approvals BC, CEC compliant.

Warranty Streamlight warrants this product to be free of defects for a lifetime of use except for batteries and bulbs, abuse and normal wear. We will repair, replace or refund the purchase price of this product should we determine it to be defective. This limited lifetime warranty also excludes rechargeable batteries, chargers, switches and electronics which have a 2 year warranty with proof of purchase. THIS IS THE ONLY WARRANTY, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARE EXPRESSLY DISCLAIMED EXCEPT WHERE SUCH LIMITATION IS PROHIBITED BY LAW. You may have other specific legal rights which vary by jurisdiction. Visit streamlight.com for full warranty information.

Description	UPC	Item #
Portable Scene Light II - 120V AC/12V DC - Red	080926-46000-3	46000
Portable Scene Light II - 230V AC/12V DC - Red	080926-46001-0	46001
Portable Scene Light II - 240V AC/12V DC - Red	080926-46002-7	46002
Portable Scene Light II - 100V AC/12V DC - Red	080926-46003-4	46003
Portable Scene Light II - 240V (AUS/NZ) AC/12V DC - Red	080926-46004-1	46004

Designed in the USA. Manufactured in China.

	Description	UPC	Item #
	12V DC power cord 10ft (3 meters)	080926-22056-0	22056
	Portable Scene Light Power Supply	080926-22083-6	22083
	Portable Scene Light Cord with 120V AC Plug - Works with Portable Scene Light power supply (22073)	080926-22074-7	22074
	Portable Scene Light Cord with 230V AC Plug - Works with Portable Scene Light power supply (22073)	080926-22075-1	22075
	Portable Scene Light Cord with 240V UK AC Plug - Works with Portable Scene Light power supply (22073)	080926-22076-8	22076
	Portable Scene Light Cord with 100V AC Plug - Works with Portable Scene Light power supply (22073)	080926-22077-5	22077
	Portable Scene Light Cord with 240V UAS/NZ AC Plug - Works with Portable Scene Light power supply (22073)	080926-22078-2	22078
	Lithium Ion Battery - 2pk	080926-46005-8	46005