

- In addition to routine checks for each use, PPE should regularly undergo a detailed inspection by a competent person. Petzl recommends an inspection every 12 months and after any exceptional event in the life of the product.
 - PPE inspection should be conducted with the manufacturer's Instructions for Use.
- Download the instructions at [PETZL.COM](https://www.petzl.com).



ASAP'SORBER

User information

Surname

Address

Identifier

PPE information

Model

Serial number

Year of manufacture

Date of purchase

Date of first use

Manufacturer: Petzl, ZI Cidex 105A - 38920 Crolles - France

☒ Good condition (G)	☐ To monitor (TM)	☐ To repair (TR)	☐ Do not use, retire (R)	☐ N/A Not applicable
---	---------------------------------------	--------------------------------------	--	---

1. Known product history

Usage conditions or exceptional event during use (examples: fall or fall arrest, use or storage at extreme temperatures, modification outside manufacturer's facilities...):

2. Preliminary observations

- Verify the presence and legibility of the serial number and the CE mark.
- Verify that the product lifetime has not been exceeded.
- Compare with a new device to verify there are no modifications or missing elements.

☒ ☐ ☐ ☐ ☐ N/A

3. Preparation

- Depending on your model, remove the CAPTIVs, carabiners and STRING, or remove the ASAP'SORBER from the ASAP LOCK.

4. Checking the condition of the energy absorber

- Check the condition of the pouch. Look for wear and damage due to use (cuts, fuzziness, signs of chemicals...).
- Open the pouch and pull out the energy absorber.
- Check the condition of the energy absorber. Look for wear and damage due to use (cuts, fuzziness, signs of chemicals...).
- Check the condition of the safety stitching on both sides. Look for any threads that are loose, worn, or cut.
- Verify that the energy absorber has not sustained an impact load (verify that none of the fabric between the straps has been torn).
- On the ASAP'SORBER international version and ASAP'SORBER AXESS, verify that the fall indicator has not been torn.
- Check the condition of the connection points. Look for wear and damage due to use (cuts, fuzziness, signs of chemicals...).
- Put the energy absorber back in the pouch and close it.
- Verify that all of the energy absorber webbing is properly protected in the pouch.

☐ ☐ ☐ ☐ ☐

5. Checking the condition of the connectors

- For connector inspection, see the inspection form for your connector model at Petzl.com.

☐ ☐ ☐ ☐ ☐

6. Checking the protection elements

- Check the condition of the STRINGS.
- Reinstall the STRINGS on the attachment points.
- Verify that the connector/sling/STRING assembly is correct.
- Verify that the STRING correctly positions the connector.
- Reinstall the connectors. If applicable, reinstall the CAPTIVs on the connectors.

☐ ☐ ☐ ☐ ☐

Comments (detail here any defects found on the product and accomplished tasks)

VERDICT

☐ Product **fit** to remain in service

☐ Product **unfit** to remain in service

Inspected by

Company

Date Next inspection date