



PROTAC® 2.0

- DESCRIPTION:** The ProTac® 2.0 is a 2,000-lumen tactical flashlight that uses a proprietary Streamlight SL-B50® protected Li-Ion rechargeable battery. The ProTac® 2.0 features a tactical tail cap switch for momentary or constant on operation and three different user-selectable programs. The Streamlight SL-B50® charges directly via USB-C port in the body of the battery. The battery is keyed to ensure proper alignment of the charging port. Packaged with a USB-C cord, removable pocket clip, and holster.
- CASE MATERIAL:** 6000 series machined aircraft aluminum with Type II MIL-Spec anodized finish. Available in black.
- DIMENSIONS:** Length: 6.10 in (155mm) Head Diameter: 1.46 in (37 mm) Body Diameter: 1.02 in (26 mm)
- WEIGHT:** 8.25 oz (234 g) with (1) Streamlight SL-B50® protected Li-Ion USB-rechargeable battery (included in purchase)
- LENS:** Glass with anti-reflective coating; gasket-sealed
- LIGHT SOURCE:** LED technology, impervious to shock with a 50,000-hour lifetime
- LIGHT OUTPUT:** See chart. Fully regulated output for consistent lumen performance over the entire battery life.
- ON/OFF:** Multi-function, push-button tactical tail switch with momentary and latching constant on operations. One-handed operation of momentary, variable intensity, or strobe mode. TEN-TAP® programmable switch allows user selection of one of three different programs: high/strobe/low (factory default), high only, or low/medium/high.
- RUN TIME:** See chart below. All run time claims are to 10% of initial lumen output.
- BATTERY:** One (1) Streamlight SL-B50® protected 4,900mAh Li-Ion USB-rechargeable battery with on-board safety control. Recharges in 6 hours.
- FEATURES:**
- 





LED technology for extreme brightness

IP67-rated; dust-tight and waterproof to 1 meter for 30 minutes.





All openings O-ring sealed.

2-meter impact resistance tested

Anti-roll face cap

Serialized for positive identification
- APPROVALS:**   Meets applicable United Kingdom and European Community Directives
 CEC Compliant
- WARRANTY:** Streamlight's Limited Lifetime Warranty
- OPTIONAL ACCESSORIES:** Holster, USB-C charge cord, SL-B50® battery

OUTPUT:

FL 1 Standard	HIGH	MEDIUM	LOW
	2000 LUMENS	570 LUMENS	100 LUMENS
	2h 30min	4h 30min	25h
	262m	142m	60m
	17,300cd	5000cd	890cd

Strobe Run Time: 4h 25min