



PROTAC® 2.0 HIGH LUMEN, TACTICAL LIGHT



Material/Lens 6000 Series machined aircraft aluminum with anodized finish. Glass with anti-reflective coating; gasket sealed.

Dims/Weight Length: 6.1 in. (155 mm); Head Diameter: 1.46 in. (37 mm); Body Diameter: 1.02 in. (26 mm)
Weight: 8.25 oz (234 grams) with one SL-B50® protected Li-Ion USB-C rechargeable battery (included in purchase).

Light Source LED technology, impervious to shock with a 50,000 hour lifetime

Output/Runtime

- High for maximum illumination: 2,000 lumens; 17,300 candela; 262m beam; runs 2.5 hours
- Medium for bright light and longer run time: 570 lumens; 5,000 candela; 142m beam; runs 4.5 hours
- Low for extended run time: 100 lumens; 890 candela; 60m beam; runs 25 hours
- Strobe for signaling or disorienting: runs 4.4 hours

Switch Multi-function, push-button tactical tail switch with momentary and latching constant on operations. One-handed operation of momentary, variable intensity or strobe mode. TEN-TAP® programmable switch allows user selection of one of three different programs: high/strobe/low (factory default), high only or low/medium/high.

Battery One (1) Streamlight SL-B50® protected 4,900mAh Li-Ion USB-rechargeable battery with on-board safety control. Recharges in 6 hours.

Features

- IP67 rated; dust tight and waterproof to 1 meter for 30 minutes
- 2 meter impact resistance tested
- Anti-roll face cap
- 2,000 lumens
- Serialized for positive identification
- All openings O-ring sealed
- TEN-TAP® Programmable switch allows user to select one of three different programs

Approvals Meets applicable United Kingdom and European Community Directives.

Warranty Streamlight warrants this product to be free of defects for a lifetime of use except for batteries and bulbs, abuse and normal wear. We will repair, replace or refund the purchase price of this product should we determine it to be defective. This limited lifetime warranty also excludes rechargeable batteries, chargers, switches and electronics which have a 2 year warranty with proof of purchase. THIS IS THE ONLY WARRANTY, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARE EXPRESSLY DISCLAIMED EXCEPT WHERE SUCH LIMITATION IS PROHIBITED BY LAW. You may have other specific legal rights which vary by jurisdiction.

Item	UPC	Part #
ProTac 2.0 Includes SL-B50 lithium battery pack, 22" USB-C cord, nylon holster	080926-89000-8	89000

	Item	UPC	Part #
	SL-B50 Battery 1 Pack	080926-22111-6	22111
	SL-B50 Battery 2 Pack	080926-22112-3	22112
	Red Safety Wand	080926-88057-3	88057
	Nylon Holster	080926-88086-3	88086
	22" USB-C cord	080926-22084-3	22084