

Booster Hose

Heavy Duty Rubber Covered

The Kochek Heavy Duty Rubber Booster Hose line is made of the highest quality materials. All configurations are made in the USA. Each hose features reliable, long-lasting aluminum alloy couplings, well known for their superior performance and durability.

Main Features

- Synthetic rubber cover and liner with a two-layer braided polyester yarn reinforcement. Thick-walled construction provides exceptional bend and crush resistance for extended service life.
- Optimized for use on hose reels in forestry and other first-response applications.
- Smooth cover provides superb abrasion protection and is highly resistant to heat, cuts, embers, and most petrochemicals.
- Smooth inner liner for maximum water flow.
- Meets and exceeds applicable NFPA 1961 standards.
- Service temperature range: 0F to 180F
- Available in 3/4" and 1" diameters, and lengths up to 200'.

Connections

- Standard indented pin lug (hole type) bar-way style couplings available with 1" NH and NPSH threads.
- Field repairable indented pin lug couplings are available optionally, with a reusable and easy to assemble two-part collar. No special tools required.
- Special threads available upon request.
- Other types of specialty couplings available upon request.

Colors & Finishes

- Hose is available in Red.
- Standard aluminum couplings are finished in natural hardcoat. This industry-standard coating offers superb corrosion and abrasion resistance.
- Powder coated couplings for color-coding are available upon request (field repairable type only).
- Chrome-plated couplings are also available upon request.

Warranty

- 1 Year Manufacturers Warranty



Optional Field Repairable Coupling

Booster Hose Heavy Duty Rubber Covered

MOST POPULAR SIZES & CONFIGURATIONS

Part Number	Nominal Hose Diameter (IN)	Hose Length (FT)	Working Pressure (PSI)	Minimum Burst Pressure (PSI)	Color	Couplings - Diameter and Type
KRBH75-50-3	0.75"	50'	800	2400	RED	1" NH SWIVEL FEMALE x MALE
KRBH75-100-3	0.75"	100'	800	2400	RED	1" NH SWIVEL FEMALE x MALE
KRBH75-200-3	0.75"	200'	800	2400	RED	1" NH SWIVEL FEMALE x MALE
KRBH10-50-3	1"	50'	800	2400	RED	1" NH SWIVEL FEMALE x MALE
KRBH10-100-3	1"	100'	800	2400	RED	1" NH SWIVEL FEMALE x MALE
KRBH10-200-3	1"	200'	800	2400	RED	1" NH SWIVEL FEMALE x MALE
KRBH10FR-50-3	1"	50'	800	2400	RED	1" NH SWIVEL FEMALE x MALE (Field Repairable)
KRBH10FR-100-3	1"	100'	800	2400	RED	1" NH SWIVEL FEMALE x MALE (Field Repairable)
KRBH10FR-200-3	1"	200'	800	2400	RED	1" NH SWIVEL FEMALE x MALE (Field Repairable)



Customizations

- Laser engraving is available.
- Other non-standard coupling types, colors, and special threads are available upon request.
- Custom lengths available, please call for part numbers.

Standard Bar-Way Style Coupling